

### INSTRUCTION MANUAL

ITEM: NJ-200



[www.naritausa.com](http://www.naritausa.com)

**Save these instructions for future use**

## English

### How to use (fig. 1-7)

- Before using for the first time, check if the voltage indicated on the base of the appliance corresponds to the voltage in your home  
Set the slide to the required position to adjust the juice sieve (fig. 5).  
**MIN:** Small holes, for juice without pulp (and pips).  
**MAX:** Large holes, for juice with much pulp (but still without pips).  
Select the small (inner) cone for lemons, limes, etc.
- The citrus press is switched on by pressing the fruit down onto the cone (fig. 6).
- (Type HR 2796.) Select the large (outer) cone for oranges, grape fruits, etc. (fig. 7).  
Select the small (inner) cone for lemons, limes, etc.
- Do not operate the appliance longer than 6 minutes without interruption.

### Cleaning (fig. 9-11)

- Wash the removable parts immediately after use. If dried, fruit pulp is more difficult to remove.  
Never immerse the motor unit in water. Clean the motor unit with a damp cloth.

THIS PRODUCT IS GUARANTEED FOR 1 YEAR FROM DATE OF PURCHASE, THE GUARANTEE IS ONLY VALID FOR TECHNICAL FAULTS NOT FOR FAULTS OF MISHANDLING THIS PRODUCT.



IF YOU EXPERIENCE ANY DIFFICULTIES USING THIS PRODUCT PLEASE RETURN IT TO THE PLACE OF PURCHASE WITH A VALID RECEIPT WHO WILL THEN REPAIR IT OR REPLACE FOR YOU.

THANK YOU.

# IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

- 1 READ ALL INSTRUCTIONS CARE-FULLY- before using the unit.
- 2 CLOSE SUPERVISION IS NECESSARY- when any appliance is used by or near children.
- 3 TO PROTECT AGAINST RISK OF ELECTRICAL SHOCK- Do not put charging base in water or other liquid.
- 4 DO NOT OPERATE in the presence of explosive and/or flammable fumes.
- 5 DO NOT OPERATE ANY APPLIANCE with a damaged cord or plug or after the appliance malfunctions, or is dropped or damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or electrical or mechanical adjustment.
- 6 MAKE SURE THE APPLIANCE IS "OFF"- and motor has stopped completely before putting on or taking off attachments, and before cleaning.
- 7 AVOID CONTACTING MOVING PARTS -Keep hands, hair, clothing, as well as spatulas and other utensils away from moving attachment during operation to prevent injury, and/or damage to the juicer.
- 8 REMOVE ATTACHMENTS from juicer before washing.
- 9 UNIT SHOULD BE USED for food preparation only.
- 10 THE USE OF ATTACHMENTS NOT RECOMMENDED OR SOLD by the appliance manufacturer may cause hazards.
- 11 THIS APPLIANCE IS INTENDED for household use only and not for commercial or industrial use.
- 12 USE CARE WHEN STIRRING HOT LIQUIDS to avoid splattering.
- 13 This appliance has a polarized plug (one blade is wider than the other ).To reduce the risk of electric shock, this plug will fit in a polarized outlet only one way . If the plug does not fit fully in the outlet , reverse the plug, if it still does not fit ,contact a qualified electrician. Do not modify the plug in any way.



## SAVE THESE INSTRUCTIONS