

NARITA®



Soymilk Maker


NSM-1500

INSTRUCTION MANUAL

IMPORTANT SAFEGUARDS

1. Read all instructions carefully and keep this manual for future reference.
2. Do not touch hot surfaces, allow metal parts to cool down before cleaning, allow the soybean milk maker to cool thoroughly before putting together or removing parts.
3. Do not place cord plug or appliance in the water or other liquids.
4. Close supervision of children is necessary when children are around the soymilk maker when in use.
5. Do not operate any appliances with a damaged cord/plug or after the appliance malfunctions or has been damage in any manner. Return appliance to an authorized service facility for examination, repair or adjustment.
6. Do not use attachments that are not recommended by the manufacturer, they may cause fire, electric shock or injury.
7. Never try to put food and /or water containers to place on the heating plate, use only the stainless steel container provided or recommended by the manufacturer.
8. Do not place the appliance on an unsteady or cloth covered surface.
9. Do not place the soybean milk maker near a hot gas or electric burner or in a heated oven.
10. Extreme caution must be used when moving an appliance containing hot liquids.
11. This appliance is for household use only. Do not use this appliance other than its intended use. Do not use outdoor or for commercial purpose.
12. Be sure unplug from power outlet when putting on or taking off the parts

GET TO KNOW YOUR MACHINE




HOW TO MAKE THE SOYBEAN MILK

1. Soak Beans:

- Use the attached 'measuring cup' to measure 1 cup of dry beans, then put the dry beans into water and let it soak for 3-12 hours for best results.

Note: This soybean milk maker can also use dry beans to make soymilk! If using dry beans to make soymilk, 1 cup 'measuring cup' (80 grams) is enough.



measuring cup

2. Add Water:

- Put water into the 'Stainless steel container', do not put more water than the 'Max' level or less than the 'Min' level water.
- If the water level is higher than the 'Max' level mark, it may overflow. If the level water is lower than the 'Min' level mark, the machine may not work.

3. Add beans:

- Put the soaked beans or dry beans into the 'Stainless steel container' (1 cup is enough for dry beans, do not exceed 2 cups of soaked beans), put the 'Poly drift net' into the motor and lock it well, then put the whole top part into the 'Stainless steel container' and make sure both the power connector are connected.

4. Make soymilk:


- Connect the power cord into the plug (located in the lower of the stainless steel container) and plug into the power outlet.
- Then press the 'Soymilk' button (the first button) on the control panel, the machine will start to work and the display screen will show the temperature. After about 20 minutes, the program will finish working and the display screen will display 'END', at this time, the machine will make a beeping sound which means the soymilk is ready for use.

- Carefully to take off the whole top part of the machine, pour out the soymilk into the net provided for pure soymilk.
(Caution: Before you take off the top part of the machine be sure to pull out the power cord)


HOW TO MAKE PASTE:

- Add water into the 'Stainless steel container', do not lower the 'Min' mark and do not exceed the 'Max' mark.
- Use the 'Measuring cup' to measure 1 cup of rice, then put it into the 'Stainless steel container', then put the 'Poly drift net' and lock it well into the motor, and connect the whole top part into the 'Stainless steel container' and make sure both power connector are connected.
- Connect the power cord and press the button 'Paste', the cooking will begin, about 20 minutes, the program will finish and the display screen will display 'END', at this time, the machine will make a beeping sound which means the paste is ready for use.


CLEANING AND CAUTION




1.wrong




2.wrong




3.right



1.wrong




2.wrong



3.right

1. After each use, clean the soymilk maker thoroughly; please see the pictures for reference.
2. Use the cleaning brush to clean the 'Poly drift net' correctly.



Important: Must clean the filter carefully, and let the hole on the filter be seen, if not, it may not grind the beans well and the milk will be thinner in next time's use.

3. Use the cleaning sponge to clean the inside of stainless steel container and sensor carefully after every used. (do not immerse the whole top part of soymilk maker in water at any time)
4. Use the soft cloth to wipe the outside of the stainless steel container. (do not immerse the stainless steel container in water at anytime)
5. During making the soymilk or paste, be sure that the water neither lower than the 'Min' mark nor exceed the 'Max' mark.
6. Please do not let the children touch or operate the soybean milk maker.
7. Unplug from power outlet when not in use or before cleaning.
8. Do not immerse the soybean milk maker (cord, plugs, motor assembly and stainless steel container) into the water or other liquids.
9. Do not touch the hot surfaces.
10. Do not use outdoors, this appliance is not design for outdoor usage.
11. Be sure unplug from power outlet when putting on or taking off the parts

TECHNICAL :

Voltage: 120V/60Hz
Motor: 200W
Power: 750W
Capacity: 1.2L-1.5L

LIMITED WARRANTY

Your Narita small kitchen appliance is warranted against defective materials or workmanship for 1 year from the date of purchase, the warranty is only valid for any manufacturing defects under normal use and conditions, and we will repairs or replaces parts at its option (defective parts at no charge) this warranty does not apply in the improper installation, misuse, abuse or damages cause from shipping. Any return of defective merchandise to the manufacturer must proceed accordingly by contacting customer service first to obtain the Return Authorization Number and freight prepaid with proof of purchase. We will not accept any returns of merchandise without an applicable RMA number.

This warranty is valid only in the United States, excluding Alaska, Hawaii, or Puerto Rico.